USER'S GUIDE

V:0903-0810-10

IBP301B

Portable Boombox for iPod and iPhone

For the most up-to-date version of this User's Guide, go to **www.ilive.net**

Warnings and Precautions

- **CAUTION**: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- **AVERTISSEMENT:** Pour réduire le risque d'incendie ou de choc électrique, ne pas exposer cet appareil sous la pluie et l'humidité.
- **CAUTION:** Use of any controls or adjustments or performance of procedures other than those herein specified may result in hazardous radiation exposure.
- **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **WARNING:** Do not place the unit on top of any soft, porous, or sensitive surfaces to avoid damaging the surface. Use a protective barrier between the unit and surface to protect the surface.
- **WARNING:** Use of this unit near fluorescent lighting may cause interference regarding use of the remote. If the unit is displaying erratic behavior move away from any fluorescent lighting, as it may be the cause.
- **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- ***PRÉCAUTION:*** *Danger d'explosion si les piles sont remplacées de façon incorrect. Remplacer les piles seulement par le même type de pile ou l'équivalent.*
- **WARNING:** There is a danger of explosion if you attempt to charge standard Alkaline batteries in the unit. Only use rechargeable NiMH batteries.
- **WARNING:** The remote control's button cell battery contains mercury. Do not put in the trash, instead recycle or dispose of as hazardous waste
- **WARNING:** Lithium batteries, like all rechargeable batteries are recyclable and should be recycled or disposed of in normal household waste. Contact your local government for disposal or recycling practices in your area. They should never be incinerated since they might explode.
- **WARNING**: Shock hazard - Do Not Open.
- ***AVIS****: RISQUE DE CHOC ÉLECTRIQUE - NE PAS OUVRIR*

  Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
  La prise du secteur est utilisé pour déconnecter le système.
  La prise du secteur ne doit pas être obstruée ou doit être facilement accessible pendant son utilisation. Pour être complètement déconnecté de l'alimentation d'entrée, la prise doit être débranchée du secteur.

  Do not mix old and new batteries.
  Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.
  No mezcle baterías viejas y nuevas.
  No mezcle baterías alcalinas, estándar (carbono-zinc) o recargables (ni-cad, ni-mh, etc.).

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Important Safety Instructions

1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding - type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.

12.
Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Additional Warnings

- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
  L'appareil ne doit pas être exposé aux écoulements ou aux éclaboussures et aucun objet ne contenant de liquide, tel qu'un vase, ne doit être placé sur l'objet.
- Main plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected form the mains socket outlet completely.
  La prise du secteur ne doit pas être obstruée ou doit être facilement accessible pendant son utilisation. Pour être complètement déconnecté de l'alimentation d'entrée, la prise doit être débranchée du secteur.
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
  Les piles ne doivent pas être exposées à de forte chaleur, tel qu'à la lumière du soleil, au feu ou autres choses de semblable.
- Caution marking is located at the bottom of the apparatus.
  Attention marquage est situé au bas de l'appareil.
- The marking information is located at the bottom of apparatus.
  Les informations de marquage est situé au bas de l'appareil.

This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

Portable Boombox for iPod and iPhone

Features

- Made for iPod and iPhone
- Plays and charges docked iPod and iPhone
- Supports Universal docking brackets
- Digital tune FM stereo radio
- Station memory presets (20 FM)
- Digital volume control
- Last user settings memory
- 3.5mm audio input
- RCA video output
- White backlit LCD display
- Built-in speakers
- Cloth speaker grill
- AC power: built-in AC power cable
- DC power: requires 4, C-size, batteries (not included)

Included

- Remote control: requires 1, CR2025, battery (included)
- Docking brackets for iPod/iPhone (5)

TABLE OF CONTENTS

Warnings and Precautions 2

Important Safety Instructions 3
- FCC Warnings
- Additional Warnings

Portable Boombox for iPod and iPhone . . 4
- Features
- Included

Introduction 6

Setup 8
- Power
- Battery Power

iPod and iPhone 9
- Docking an iPod or iPhone
- Playing a Docked iPod or iPhone

Radio 10
- Tuning the FM Radio
- Saving a Radio Station as a Preset
- Tuning to a Preset Station

Audio Input and Video Output 11
- Using the 3.5mm Audio Input
- Using the Composite Video Output

Company Information 12
- International Support
- Contact Information

Introduction

SLEEP
Press repeatedly to set the sleep timer. When the set time expires, the boombox will automatically power off.

SOURCE
Press to adjust the boombox's current source.

POWER
Press to power the boombox off or on.

VOLUME
Press to adjust the volume.

DISPLAY

STOP
Press to stop a docked iPod or iPhone during play.

PLAY/PAUSE
Press to play or pause a docked iPod or iPhone.



SKIP/SEARCH/TUNE ±
Press to skip between tracks on a docked iPod or iPhone. Press and hold to search through an individual track on a docked iPod or iPhone. Press to tune the FM radio in radio mode.

MEM
Press to save the current radio station as a preset.

COMPOSITE VIDEO OUTPUT



3.5MM AUDIO INPUT

BATTERY COMPARTMENT
Requires 4, C size, batteries (not included)



POWER
Press to power the boombox off or on.

SLEEP
Press repeatedly to set the sleep timer. When the set time expires, the boombox will automatically power off.

MENU ▲ ▼
Press to navigate the current menu on a docked iPod or iPhone.

ENTER
Press to make selections on a docked iPod or iPhone.

MUTE
Press to mute the volume.

iPod MENU
Press to cycle through the menus on a docked iPod or iPhone.

SOURCE
Press to adjust the boombox's current source.

SKIP/SEARCH/TUNE ±
Press to skip between tracks on a docked iPod or iPhone. Press and hold to search through an individual track on a docked iPod or iPhone. Press to tune the FM radio in radio mode.

PLAY/PAUSE
Press to play or pause a docked iPod or iPhone.

MEM
Press to save the current radio station as a preset.

VOLUME
Press to adjust the volume.

TREBLE
Press to adjust the treble.

BASS
Press to adjust the bass.

Setup

Power

Plug the built-in AC power cable into a standard AC power outlet to power the unit.



Battery Power

Requires 4, C size, batteries (not included)





Docking an iPod or iPhone

1. Locate the numbered bracket that fits the iPod or iPhone model that will be docked.

   Each included bracket has a number on it, indicating which iPod or iPhone model that bracket is compatible with. See the separate bracket chart page to identify which bracket is needed.

2. Snap the bracket into place over the iPod and iPhone connector in the dock.
3. Connect the iPod or iPhone to the connector inside the Dock for iPod and iPhone.
4. When the dock is plugged in, using AC power, the docked iPod or iPhone will charge.

Playing a Docked iPod or iPhone

1. Follow the instructions for Docking an iPod or iPhone.
2. Press the **SOURCE** button to switch to iPod mode.
3. Press the **PLAY/PAUSE** button to begin playing the docked iPod or iPhone.

Radio

Tuning the FM Radio

1. Press the **SOURCE** button to switch to FM radio mode.
2. Press the **TUNE±** buttons to adjust the FM radio station.

   Extend the **FM ANTENNA** *to improve FM radio reception.*

Saving a Radio Station as a Preset

1. Follow the instructions for Tuning the FM Radio.
2. Tune to the desired station.
3. Press and hold the **MEM** button for 1-2 seconds.

   The display will begin to flash.
4. Press the **TUNE±** buttons to select the preset the current station will be set to.
5. Press the **MEM** button to save the current station to the selected preset.

Tuning to a Preset Station

1. Follow the instructions for Tuning the FM Radio and Saving a Radio Station as a Preset.
2. Press the **MEM** button repeatedly to cycle through preset radio stations.

Audio Input and Video Output

Using the 3.5mm Audio Input

Requires a 3.5mm audio cable (not included)

1. Connect a 3.5mm audio cable to the **3.5MM AUDIO INPUT** on the boombox and an audio output on an MP3 player or other audio source.
2. Press the **SOURCE** button to switch to LINE IN mode.
3. Use the native controls on the connected MP3 player or other audio source to play and control audio played through the boombox.

Using the Composite Video Output

Requires an RCA video cable (not included)

1. Connect an RCA video cable to the **COMPOSITE VIDEO OUTPUT** on the boombox and a video input on a television.
2. Adjust the television to the input mode that matches the connection used in step 1.
3. Video played through a docked iPod or iPhone will now play through the connected television.

Company Information

International Support

To download this User's Guide in English, Spanish, or French, visit the support section at www.ilive.net.

Para transferir esta guía de usuario en inglés, español, o francés, visite la sección de la ayuda en www.ilive.net.

Pour télécharger ce guide de l'utilisateur en anglais, espagnol, ou français, visitez la section de soutien chez www.ilive.net.

Contact Information

Phone: 1-888-999-4215
Email: customerservice@ilive.net
Parts Email: partsinfo@dpi-global.com
Website: www.ilive.net

Copyright © 2010 Digital Products International (DPI, Inc.) | All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice